



18	1	Key	05-03-727
17	2	Ballbearing	05-08-123
16	1	O-ring	05-06-500
15	1	Lipseal	05-24-105
14	1	SKRUV	05-04-117
13	6	SKRUV	05-04-162
12	1	Locking Retaining ring	05-34-1
11	1	Bushing	01-40046
10	1	Supporting Guide	01-40024
9	1	Strike Washer	01-45186
8	1	Split Pin	01-42400
7	1	Silfbricka - Wear plate	01-42399
6	1	Lock - Endcover	01-42398
5	1	Packing - Gasket	01-42401
4	1	Impeller - Impeller	08-1027 A
3	1	Cam - Cam	01-42397
2	1	Axel - Shaft	01-45553
1	1	Humphus - Body	01-24184-1

Johnson Impellerpump  
10-24184-1